



ATTACHING YOUR CURVED CANOPY



(PLEASE NOTE: The image above shows a 2m canopy on a Classic Boutique Camping Bell Tent; the same instructions apply for all sizes and designs.)

- 1** Firstly, unpack your canopy and lay it flat on a clean and dry surface, free from any sharp objects.
- 2** Locate the flexi pole and carefully thread it into the funnel on the longest edge (point **A** or **B**) This is also the side that has the guy ropes attached.
- 3** Insert the metal pins either end to start creating the curve. This coupled with the detachable webbing strap should give you an even arch.
- 4** Locate the midpoint on the opposite longest edge, this can be located via the brass eyelet (point **C**) Please connect this point onto the external A-Frame spike found on your tent doorway.
- 5** Using the pegs provided, peg out either side of the tent (point **D**) Please make sure point **C** to **D** is tight.
- 6** Next, pull out points **A** & **B** until the right tension has been created & peg down.
- 7** It's now time to peg out the guy ropes, this stage will create the final shape of the canopy. Each guy rope should be 100-150cm away from the canopy.



(Please note: The webbing between **A** and **B** can be removed once everything is in place to avoid trip hazards)

